



60255 Installation Instructions

Step 1

- Install A-Frame (55015) on Jeep.



Step 2

- Align holes of Katwalk (60255) with the PEMNUTS on A-Frame (55015). Bolt together using four 3/8"-16 x 1", four 3/8" split lock washers and four 3/8" flat washers.

